

## Thermometer Testing Record

Any thermometers that are used should be tested monthly for accuracy.

### Low temperature readings

The tip of the probe should be placed in a container holding some crushed ice and water. The reading should be taken after 5 minutes and the result recorded below. The reading should be between  $-1^{\circ}\text{C}$  and  $+1^{\circ}\text{C}$ .

### High temperature readings

The tip of the probe should be placed in a container holding boiling water. The reading should be taken and recorded below. The reading should be between  $+99^{\circ}\text{C}$  and  $+101^{\circ}\text{C}$

### Irregular readings

In the event of a series of irregular readings check that the battery is functioning properly or send the unit back to the manufacturer for re-calibration.

Month/Year	Temp Recorded		Action/comments	Signed
	Hot	Cold		
Jan/				
Feb/				
Mar/				
Apr/				
May/				
Jun/				
Jul/				
Aug/				
Sep/				
Oct/				

Nov/				
Dec/				